


USER MANUAL



Item: 32401

Product: Koozie® Fabric Waterproof Bluetooth® Speaker

Features:

- Fabric grills, fabulous touch.
- Water-resistant, on matter it is rainy day or in shower, enjoy your favorite music in anytime and anywhere.
- Light weight, hook designed to carry around.
- Compatible with all Bluetooth enabled smartphones, tablets and laptops.

Package includes:

Bluetooth speaker x1

User manual x1

Micro USB charging cable x1

AUX in cable x1

Product Specifications

Bluetooth: 5.0

Li-ion battery: 3.7V/2000mAh

Speaker Driver: 7.5W

Operating frequency range: 2.40GHz-2.48GHz


Charging time: 3 – 4 hours

Playing time: 10 hour with 50% volume

Wireless range: 30 feet

(Wireless range varies depends on environment and battery level)

Key and Connection:



1. ON/OFF
2. Volume - / or Previous
3. Volume + / or Next
4. Play/Pause
5. AUX in port
6. Charging port / Charging indicator

Easy pairing (first time pairing):

1. Power on Bluetooth speaker.
2. Bluetooth speaker will automatically enter pairing mode(flashing blue light)
3. Search for "32401" on pairing device (refer to device user manual)
4. Enter password/pin is "0000" if required
5. The Pairing process will finish automatically. (staying blue light when process is complete, flashing blue light slowly when play music)

Manual pairing:

1. With Bluetooth speaker off. Press and hold "ON/OFF" button and power up Bluetooth speaker.
2. Repeat easy pairing step 3-5

Note: Bluetooth speaker will turn off automatically if not paired within 5 minutes

Music control:

Play: press play/pause button

Pause: press the play/pause button

Volume up: short-pressed the volume+ button

Volume down: short-pressed the volume- button

Next song: long-pressed Next button

Previous song: long-pressed previous button

General Operation

How to use:

- Make sure the device is charged fully before using for the first time. Please use the included micro USB Cable for charging.
- In order to maintain the power of battery, charge and discharge the device every 3 months, even you do not use it.

Safety instructions

- Do not disassemble, repair or modify this product by yourself, contact to your authorized specialist.
- Use extra caution in high temperatures;
- Do not use product in a hospital or on an airplane;
- Do not expose the device to direct sunlight, heat or flame;
- Product is not covered under warranty when the product has metal rust, surface spalling and any other natural oxidation;
- Damage, shock, and/or injury can occur if these warnings are not heeded;
- Device may become warm while charging;
- Make sure you always turn the product off and the power outlet off completely before unplugging the product;
- Make sure the product has plenty of ventilation;
- Do not press the buttons too hard as it could damage the product;
- Only use dry cloth to keep product clean from dust;
- Do not use chemicals on this product;
- Do not insert foreign objects into the product;
- Avoid dropping the product, as harsh impacts could damage the product.
- Never store or use this product in temperatures below 32°F (0°C) or above 115°F (45°C)



FCC ID:2AIKE-719826
CHINA